




Marka:	TRESNAR
Model:	(4660)

Item No.	Part Name	Item No.	Part Name	Item No.	Part Name
1	Front cover	31	Small oil bearing	61	Knob
2	Clip ring	32	Oil bearing	62	Bearing
3	Steel ball block	33	Knob assembly	63	Rotor
4	Steel ball block spring	34	Screw	64	Bearing
5	Steel ball block spring plate	35	Gear box	65	Anti-wind ring
6	Clip ring	36	Oil cover	66	Screw
7	Oil sealing	37	Spindle	67	Stator
8	Screw	38	Label	68	Housing
9	Spring plate	39	Bering	69	Screw
10	Flat plate	40	Clip ring	70	Carbon brush holder
11	Front placket	41	Clip ring	71	Carbon brush
12	Sealing gasket	42	Top hammer spring	72	Carbon brush holder cover
13	Clip ring	43	Flat key	73	Left handle
14	Bearing	44	First gear	74	Screw
15	Steel ball	45	Support sleeve	75	Switch
16	Big gear	46	Top hammer	76	Capacitance
17	O ring	47	Needle bearing	77	Screw
18	O ring	48	Small gear	78	Cable clamp
18	Impact hammer	49	Small gear distance set	79	Cable sheath
20	Steel ball	50	Bering	80	Cable
21	Cylinder	51	Small gear bearing gasket	81	Right handle
22	Flat key	52	Friction plate gasket		
23	Big spring plate	53	Friction plate	201	Dust cover
24	Big spring	54	Second gear	202	Flat chisel
25	Big gear	55	Friction plate gasket	203	Point chisel
26	Air hammer	56	Spring plate	204	Drill
27	O ring	57	Special screw	205	Drill
28	Piston	58	Bearing	206	Drill
29	Piston pin	59	Butterfly block	207	Blow case
30	Connecting rod	60	Middle cover	501	Small gear assembly
				502	Side handle assembly

Marka:	TRESNAR
Model:	(4660)