




Marka:	TRESNAR
Model:	4537

Item No.	Part Name	Item No.	Part Name
1	Screw	27	Rotor
2	Screw	28	Nut
3	Screw	29	Ball bearing
4	Label	30	Center bracket
5	Right housing	31	Fixing nut
6	Positing bearing	32	Tip block
7	Pin	33	Roller
8	Circlip	34	Balance block
9	Idler pulley	35	Needle bearing
10	Idler pulley bracket	36	Eccentric gear assy
11	Pin	37	Washer
12	Guide	38	Circlip
13	Baseplate guard	39	Pulley
14	Screw	40	Reciprocating lever
15	Pressure plate	41	Spring
16	Base plate	42	Locating block
17	Speed switch	43	Dust collect
18	Switch	44	Left housing
19	Soft grip	45	Dust-proof block
20	Cable clamp	46	Safety level
21	Cable jacket	47	Protective guard
22	Hex wrench	48	Sliding
23	Plug	49	Pin
24	Stator	50	Spring
25	Bearing	51	Adjusting knob
26	Carbon brush assy	52	Label

Marka:	TRESNAR
Model:	4537